





Casse SR
SR enclosures



ABB

ABB SACE S.p.A.
Automation and Distribution Boards Division
22040 Garbagnate Monastero (LC) - Italy
Via Italia, 58
Tel.: +39 031 3570.111 - Telefax: +39 031 3570.228

<http://bol.it.abb.com>

ABB

	A	B	A1	B1
SR 3215	237	263	163	337
SR 3315	337	263	263	337
SR 3415	437	263	363	337
SR 4315	337	363	263	437
SR 4320	337	363	263	437
SR 4420	437	363	363	437
SR 4620	637	363	563	437
SR 5320	337	463	263	537
SR 5420 SR 5420V	437	463	363	537
SR 5425 SR 5425V	437	463	363	537
SR 6420 SR 6420V	437	563	363	637
SR 6425 SR 6425V	437	563	363	637
SR 6625	637	563	563	637
SR 7520 SR 7520V	537	663	463	737
SR 7525 SR 7525V	537	663	463	737
SR 8625 SR 8625V	637	763	563	837
SR 8630 SR 8630V	637	763	563	837
SR 8830	837	763	763	837
SR 10625 SR 10625V	637	963	563	1037
SR 10630 SR 10630V	637	963	563	1037
SR 10830 SR 10830V	837	963	763	1037
SR 12630 SR 12630V	637	1163	563	1237
SR 12830 SR 12830V	837	1163	763	1237

